

Installation Instructions

STAR SYSTEM®

Pump Installation

1. Install the mounting bracket to the back of the pump using one of the black phillips head screws.
2. Tighten the other two black phillips head screws into the tank wall inserts.
3. Secure the pump to the tank by slipping the mounting bracket of the pump over the screws on the tank wall.

Suction Tube Installation

1. Attach the bottom of the flow indicator assembly to the footvalve. Tighten down the tube nut to the footvalve neck. Make sure the arrow and the face of the flow indicator assembly are facing upward in the direction of flow.
2. Attached the top of the flow indicator assembly to the bottom cartridge valve of the pump head. Tighten the tube nut to the cartridge valve.
3. Make sure all tube nuts are securely tightened (hand tighten only).

Blue-White[®]
Industries, Ltd.

5300 Business Drive
Huntington Beach, CA 92649
USA

Phone: 714-893-8529 **FAX:** 714-894-9492
E mail: sales@blue-white.com or techsupport@blue-white.com
Website: www.blue-white.com